


NIMFE-EM12/4.0L61-UP6X-H1141/S1182 Magnetic Field Sensor – With TIN Coating For Detection of Ferromagnetic Parts






| Туре | NIMFE-EM12/4.0L61-UP6X-H1141/ S1182 |
|---|---|
| ID | 1600621 |
| Remark to product | Optimized for the detection of weld nuts of the size of M5 to M10 |
| Special version | S1182 Corresponds to:TIN coating |
| General data | |
| Electrical data | |
| Operating voltage U _B | 1030 VDC |
| Ripple U _{ss} | ≤ 10 % U _{Bmax} |
| DC rated operating current I _e | ≤ 100 mA |
| No-load current | ≤ 15 mA |
| Residual current | ≤ 0.1 mA |
| Isolation test voltage | 0.5 kV |
| Short-circuit protection | yes/Cyclic |
| Voltage drop at I _e | ≤ 1 V |
| Wire break/reverse polarity protection | yes/Complete |
| Output function | 3-wire, Connection programmable, PNP |
| Mechanical data | |
| Design | Threaded barrel, M12 x 1 |
| Dimensions | 61 mm |
| Housing material | Stainless steel, 1.4301 (AISI 304) |
| Active area material | Stainless steel, 1.4301 (AISI 304), TIN coating |
| Max. tightening torque of housing nut | 10 Nm |
| Electrical connection | Connector, M12 × 1 |



Features

- ■DC 3-wire, 10...30 VDC
- NC/NO parametrizable with teach adapter VB2-SP1
- ■M12 x 1 male connector

Wiring diagram



Functional principle


The weld sensors are available in different versions, with different signal intensities and diameters. Ferromagnetic parts which differ strongly in their material properties and diameters can thus be detected. A component to be detected must be located within the so-called optimal sensitive area in order to be detected.

This optimal sensitive area has a width of 0.5 mm and is laser-engraved on the tip of the probe, 11. 9 mm above of the M12 thread.




Technical data

| Environmental conditions | |
|--------------------------|---|
| Ambient temperature | -25+70 °C |
| Vibration resistance | 55 Hz (1 mm) |
| Shock resistance | 30 g (11 ms) |
| Protection class | IP67 |
| MTTF | 874 years acc. to SN 29500 (Ed. 99) 40 °C |
| Power-on indication | LED, Green |
| Switching state | LED, Yellow |




Mounting instructions



The magnetic field sensor for detection of ferromagnetic spares is especially suited for the detection of welding nuts as well as spacer or reinforcing sleeves. The parts to be detected must always consist of ferromagnetic material, so that a proper function can be guaranteed. Most applications need center bolts to tack the welding nuts and reinforcing sleeves in place and thus provide mechanical protection of the sensors. Theses bolts must be made of non-ferromagnetic material, like stainless steel for example. Center bolts are not available at Turck, as these have to be individually produced for and adjusted to the correspondent application.



Parameterization via teach adapter



The measured signal in the sensor is influenced by the diameter and the material characteristics of the center bolt, but also by the cover of the sensitive area. Therefore, to ensure the correct switching behavior, each sensor must be conditioned to the operating environment, i.e. to the centering sleeve or closure cap used and the component to be detected (nut, sleeve, etc.). To configure a sensor, the teach adapter VB2-SP1 available from Turck is required.

Fault indication

If an overcurrent or short circuit fault occurs when the output is switched on, the output is toggled immediately. Within one second the sensor checks whether the state of short circuit still remains and, if not, the output is switched on again. During an overcurrent or short circuit, the yellow LED flashes at a frequency of 1 Hz. Each sensor monitors internal sensor signals and hardware components. This includes the following fault sources that lead to the shutdown of the output:

- Failure of the sensor signal (e.g. due to external magnetic fields)
- Overtemperature (device internal temperature > 100 °C)
- Defective hardware

Sensor faults are indicated by the green and yellow LEDs flashing alternately. The sensor faults are usually self-resetting, i.e. the sensor reverts automatically to the normal operating state once the fault is corrected.

After the operating voltage of the sensor is switched on, the sensor checks its operating parameters. If these parameters are incorrectly configured, the sensor remains in a fault state (green LED flashes). The output cannot be switched in this state. The device parameters must be reconfigured using the teach adapter.

Comprehensive portfolio

With the NIMFE product series, Turck provides an established series of sensors for the reliable detection of weld nuts. The devices made of brass or stainless steel are available with different tip diameters from 4.0 mm to 6.2 mm and are optimized for the dimensions of the weld nuts used. The sensors are suitable for detecting weld nuts in sizes M5 to M20.


The tips of the stainless steel sensors have a coating of titanium nitride (TiN). The ceramic material, which has exceptional hardness and corrosion resistance, makes the devices more resistant to scratches and provides additional protection against wear. It also protects the sensors from weld splatter. The chemically resistant tips of the TiN-coated sensors can withstand high temperatures and feature good non-stick properties.




Teach adapter

Accessories

VB2-SP1 A3501-29 BST-12B 6947212






Mounting clamp for threaded barrel sensors, with dead-stop; material: PA6



MW12 6945003



Mounting bracket for threaded barrel sensors; material: Stainless steel A2 1.4301 (AISI 304)

BSS-12

6901321

Mounting clamp for smooth and threaded barrel sensors; material: Polypropylene

